

NATURAL STONE OR SOLID SURFACE UNDERMOUNT SINK INSTALLATION INSTRUCTIONS

PROFESSIONAL INSTALLATION RECOMMENDED | SE RECOMIENDA LA INSTALACIÓN POR PARTE DE UN PROFESIONAL

INSTRUCCIONES DE INSTALACIÓN DE FREGADEROS EMPOTRADOS DE SUPERFICIE SÓLIDA O PIEDRA NATURAL

Only use natural stone or solid surface countertops, such as acrylic, granite, marble and other composite material, for undermount installations. Franke Consumer Products accepts no liability for damage to solid surface countertops or sink fixtures during installation. Because the mounting of undermount sinks to any countertop material is a specialized procedure, we recommend that it be performed by a trained, professional installer.

A cutting mistake will be costly. *We recommend comparing the template provided to the sink before cutting the countertop.*

CAUTION: This sink may contain sharp edges. Please handle with care. Gloves are recommended.

Installation Instructions

1 Step 1: Determine Position of Sink
Locate the position of the sink using the template provided and make the cutout from the countertop.

NOTE: This template will align the edge of the counter top to the tangent of the top radius of the bowl. (SEE ILLUSTRATION) Therefore, the enclosed template is not suitable if you wish to see more sink flange (lip). This type of installation should be performed by a trained, professional installer.

2 Step 2: Determine Position of Mounting Brackets
Align the bowl under the countertop cutout and determine the location for the mounting brackets.

Type of fasteners and attachment method to be recommended by countertop supplier. Brackets have been supplied.

3 Step 3: Attach the Mounting Brackets
Attach the mounting brackets loosely to the countertop from underneath, using the fastener and attachment method recommended by the countertop supplier.

4 Step 4: Apply Silicone Sealant
Apply a continuous bead of silicone sealant around the top flange (lip) of the sink.

5 Step 5: Sink Alignment and Mounting
Align the bowl with the countertop cutout from underneath and fully tighten the brackets against the sink flange (lip).

6 Step 6: Remove Any Excess Sealant

Solo se deben usar encimeras de superficie sólida o piedra natural, como superficies acrílicas, de granito, mármol y de otros materiales compuestos para realizar instalaciones empotradas. Franke Consumer Products no se responsabiliza por los daños provocados en las encimeras de superficies sólidas o en los accesorios de los fregaderos durante la instalación. Dado que la instalación de fregaderos empotrados en cualquier material de encimera es un procedimiento especializado, recomendamos que la realice un instalador profesional capacitado.

Un error de corte será costoso. *Recomendamos comparar la plantilla incluida con el fregadero antes de cortar la encimera.*

PRECAUCIÓN: este fregadero puede contener bordes filosos. Manipúlelo con cuidado. Se recomienda usar guantes.

Instrucciones de instalación

1 Paso 1: Determinar la posición del fregadero
Calcule la posición del fregadero usando la plantilla incluida y realice un recorte de la encimera.

NOTA: esta plantilla alineará el borde de la encimera con la tangente del radio superior del recipiente. (VEA LA ILUSTRACIÓN). Por lo tanto, la plantilla incluida no es adecuada si desea ver más reborde (filo) del fregadero. Este tipo de instalación debe estar a cargo de un instalador profesional capacitado.

2 Paso 2: Determine la posición de los soportes de montaje
Encuadre el recipiente debajo del recorte de la encimera y determine la ubicación de los soportes de montaje.

El proveedor de la encimera puede recomendarle tipos de selladores y métodos de fijación. Se incluyen los soportes.

3 Paso 3: Coloque los soportes de montaje
Coloque los soportes de montaje sin ajustarlos a la encimera desde la parte inferior, usando el sellador y el método de fijación recomendado por el proveedor de la encimera.

4 Paso 4: Aplique sellador de silicona
Aplique una línea continua de sellador de silicona alrededor del borde (filo) superior del fregadero.

5 Paso 5: Encuadre y montaje del fregadero
Encuadre el recipiente con el recorte de la encimera desde la parte inferior y ajuste completamente los soportes contra el borde (filo) del fregadero.

6 Paso 6: Retire el excedente del sellador

